



Bistro models are shipped fully assembled. The oven can be moved into place with a pallet jack using the forklift pockets. If the oven is to be installed against a wall, leave access to the back of the oven to complete the utility connections.

If you need to disassemble the oven to move it through a narrow door or passageway, see the DISASSEMBLY section in this manual.

USING A FORKLIFT | PALLET JACK

Bistro ovens are very top-heavy. **If the oven tips it can cause severe injury or death. Never use a Hand Truck to move the oven.** If the oven must be moved over an inclined surface, a forklift or other suitable means should be employed. If the installer does not have the equipment or experience required to move the oven safely, we recommend securing the services of a qualified rigging company.

The oven should only be moved using a Pallet Jack on a smooth, LEVEL FLOOR.


LEVELING AND SHIMMING THE OVEN

The installed oven must be level. Use metal shims to level the oven if necessary. Because the weight of the oven is carried by the full perimeter of the oven stand, make certain there are no gaps larger than approximately 1/2" where the oven stand is unsupported by shims. Seal any small gaps between the oven and the floor with silicone. Failure to solidly support the full perimeter of the oven stand can result in costly damage to the oven and will void the warranty. The floor design and construction must be adequate to handle the weight of the oven.

Please see woodstone-corp.com for floor loading information.

⚠ WARNING			
Minimum Required Forklift Capacities			
Model	Approximate Ship Weight	Required Forklift Capacity	Min. Fork Length
BL-3030	1,100 lbs	2,000 lbs	4'
BL-4343	2,100 lbs	3,200 lbs	5'
BL-4355	2,500 lbs	5,000 lbs	
BL-4836	1,850 lbs	3,200 lbs	


MOVING THE OVEN



The oven should only be moved using a Pallet Jack on a smooth, LEVEL FLOOR. Use a forklift or other suitable means if the oven must be moved over an inclined surface.



Never use a Hand Truck to move the oven.



Make sure the Pallet Jack wheels do not contact the underside of the fork pocket when lifting to avoid damaging the stand.

USING A CRANE

The oven arrives with Pickeys attached. When craning a Wood Stone oven, use a Spreader Bar with a two-legged sling rigged on each end. The spreader bar should be of a sufficient length to keep the sling from contacting the oven, and oriented as shown in fig. 1.

PICKEYE CAPACITIES PER BEAM

1,300 lbs: Inner holes (BL-3030)

2,000 lbs: Middle holes (BL-4343, BL-4355)

2,700 lbs: Outer holes (BL-4836)

